

TABLE OF CONTENTS

	Page
SECTION 1	
1.1 LOCATION OF HOMER HADLEY BRIDGE.....	1-2
1.2 PURPOSE OF MANUAL	1-2
1.3 SCOPE OF THE MANUAL	1-2
1.4 OVERVIEW OF THE BRIDGE	1-2
1.5 OPERATIONAL RESPONSIBILITIES	1-3
1.5.1 Bridge Preservation Office.....	1-3
1.5.2 Mercer Island Bridge Crew	1-3
1.5.3 Traffic Systems Management Center (TSMC).....	1-3
1.6 INSPECTION RESPONSIBILITIES	1-4
1.6.1 Bridge Preservation Office.....	1-4
1.6.2 Mercer Island Bridge Crew	1-5
1.6.3 Special Inspections Due to Storms or Earthquakes.....	1-5
1.7 MAINTENANCE RESPONSIBILITIES	1-5
1.7.1 Bridge Preservation Office.....	1-5
1.7.2 Mercer Island Bridge Crew	1-6
1.8 INSPECTION ACCESS.....	1-6
1.9 PERSONNEL SAFETY	1-6
1.10 REVISIONS TO MANUAL.....	1-6
Revision to the OIM Manual Form	1-7

FIGURES

1.1 General Plan and Elevation	1-8
1.2 Elevated Span Layout	1-9
1.3 Anchor Cable Layout.....	1-10
1.4 Anchor Cable Information	1-11

SECTION 2

2.1	INTRODUCTION.....	2-3
2.2	NORMAL OPERATION STATUS.....	2-3
2.3	REMOTE MONITORING AND CONTROL PANEL OPERATION.....	2-4
2.3.1	Red Indicator Light and Annunicator Alarm Horn	2-4
2.3.2	Bypass On Indicator.....	2-5
2.3.3	Pontoon Lights On Indicator	2-5
2.3.4	Pontoon Lights Out Pushbutton	2-5
2.3.5	Breaker Fault Alarm Indicator	2-5
2.3.6	Transformer High Temp Alarm Indicator	2-5
2.3.7	Smoke Detector Alarm Indicator	2-6
2.3.8	Water Level Alarm Indicator	2-6
2.3.9	Navigation Lights On/Off Pushbutton	2-6
2.3.10	Alarm Volume Dial.....	2-6
2.3.11	Lamp Test Pushbutton.....	2-6
2.4	HH BYPASS PANEL OPERATION	2-7
2.4.1	Smoke Bypass Switch	2-7
2.4.2	Temp Bypass Switch.....	2-7
2.4.3	Breaker Bypass Switch.....	2-8
2.4.4	Bridge Bypass Switch	2-8
2.4.5	Water Bypass Switch.....	2-8
2.5	EMERGENCY ALARMS AND CONDITIONS	2-9
2.5.1	Breaker Fault Alarm.....	2-9
2.5.2	Transformer High Temp Alarms	2-10
2.5.3	Smoke Detector Alarm.....	2-11
2.5.4	Water Level Alarm.....	2-12
2.5.5	Auto Dialer Notification.....	2-12
2.5.6	Navigation Light Failure	2-13
2.5.7	Weather Station	2-13
2.5.8	Earthquake.....	2-14
2.5.9	Power Outage	2-14
2.6	PONTOON DEWATERING	2-14
2.6.1	Procedure for Operating the Godwin Pump	2-15
2.6.2	Procedure for Operating the Grindex Pump and Generator	2-17

SECTION 3

3.1	PURPOSE.....	3-2
3.2	GENERAL INSPECTION INFORMATION	3-2
3.2.1	Safety Equipment - Portable GFCI Cord Sets.....	3-2
3.2.2	Safety Equipment - Personal Light Source (Flashlight).....	3-2
3.2.3	Lockout/Tagout Procedures	3-2
3.3	HOW THIS SECTION IS STRUCTURED.....	3-2
3.4	PONTOON INTERIOR.....	3-2
3.4.1	Cells.....	3-4
3.4.2	Watertight Doors	3-4
3.4.3	Connection Bolts	3-6
3.4.4	Catwalks and Ladders	3-7
3.4.5	Bridge Drain System (Pontoon Interior)	3-7
3.5	PONTOON EXTERIOR.....	3-8
3.5.1	Top Slab	3-8
3.5.2	Access Hatches.....	3-9
3.5.3	Piers.....	3-10
3.5.4	Bearings.....	3-11
3.5.5	Girders.....	3-12
3.5.6	Outside Wall.....	3-13
3.5.7	Roadway Deck and Sidewalk.....	3-14
3.5.8	Traffic Barriers	3-15
3.5.9	Bridge Drain System (Pontoon Exterior)	3-16
3.5.10	Air Vents	3-17
3.5.11	Deck Expansion Joints	3-17
3.5.12	Modular Joints.....	3-18
3.5.13	Boater Protection System.....	3-19
3.5.14	Fire Hydrants.....	3-20

SECTION 4

4.1	PURPOSE.....	4-3
4.2	GENERAL INSPECTION AND MAINTENANCE INFORMATION	4-3
4.2.1	Safety Equipment - Portable GFCI Cord Sets.....	4-3
4.2.2	Safety Equipment - Personal Light Source (Flashlight).....	4-3

4.2.3	Lockout/Tagout Procedures	4-3
4.2.4	General Mechanical Inspection	4-3
4.2.5	General Mechanical Maintenance	4-3
4.2.6	Fastener Inspections	4-4
4.2.7	Electrical Insulation Resistance Tests	4-4
4.3	HOW THIS SECTION IS STRUCTURED.....	4-4
4.4	MECHANICAL EQUIPMENT.....	4-4
4.4.1	Hydraulic Pump.....	4-5
4.4.2	Hydraulic Ram	4-6
4.4.3	Saddles and Cable Socket.....	4-8
4.4.4	Steel Members in Anchorage Assembly	4-9
4.4.5	Port Cover	4-9
4.4.6	Cable Tension Adjustment	4-10
4.4.7	Bilge Piping System	4-12
4.4.8	Bilge Pumps	4-12
4.5	PONTOON EXTERIOR – ELECTRICAL ITEMS.....	4-14
4.5.1	Incoming Service Medium Voltage Switchgear.....	4-14
4.5.2	Photoelectric Cell Controller.....	4-15
4.5.3	Navigation Lights	4-16
4.5.4	Dupline Control System Panel	4-17
4.5.5	Remote Monitoring and Control Panel	4-19
4.5.6	Electrical Conductors	4-20
4.5.7	Sidewalk Lights.....	4-20
4.5.8	Weather Monitoring Station.....	4-21
4.5.9	Motorist Aid Telephone System.....	4-22
4.6	PONTOON INTERIOR – ELECTRICAL ITEMS.....	4-22
4.6.1	Medium Voltage Fuses.....	4-22
4.6.2	Medium Voltage Transformers	4-23
4.6.3	P1 Panels – Power Distribution Panel	4-24
4.6.4	P2 Panels – Pontoon Lighting Panel	4-25
4.6.5	P3 Panels – Control System	4-27
4.6.6	P4 Panels – Control System	4-28
4.6.7	P5 Panels - Water Sensor Monitoring	4-30
4.6.8	Cathodic Protection System	4-32
4.6.9	Water Sensors.....	4-34

4.6.10	Smoke Detector System	4-34
4.6.11	Pontoon Lighting System	4-35
4.6.12	Pontoon Receptacle System	4-36
4.6.13	Intercom Communication System	4-36
4.6.14	Electrical Conductors	4-37

SECTION 5

	TYPICAL CELL.....	5-3
	AIR VENT.....	5-4
	WATERTIGHT DOOR.....	5-5
	CONNECTION BOLTS.....	5-6
	BRIDGE DRAIN SYSTEM	5-7
	ACCESS HATCH.....	5-8
	PIER AND GIRDERS	5-9
	ELASTOMERIC PAD BEARING – FIXED (EXPANSION SIMILAR)	5-10
	PINNED BEARING	5-11
	ROADWAY DECK AND SIDEWALK	5-12
	PONTOON NORTH FACE	5-13
	PONTOON SOUTH FACE	5-14
	BRIDGE DRAIN GRATING	5-15
	EXPANSION JOINTS.....	5-16
	BOATER PROTECTION.....	5-17
	HYDRAULIC PUMP	5-18
	ANCHORAGE ASSEMBLY-I	5-19
	ANCHORAGE ASSEMBLY-II	5-20
	ANCHORAGE ASSEMBLY-III	5-21
	BILGE PIPING	5-22
	BILGE PUMPING PORTS ON LOWER DECK.....	5-23
	BILGE PUMPS.....	5-24
	INCOMING SERVICE MEDIUM VOLTAGE SWITCHGEAR	5-25
	PHOTOELECTRIC CELL CONTROLLER.....	5-26
	NAVIGATION LIGHT	5-27
	DUPLINE CONTROL SYSTEM PANEL - I	5-28
	DUPLINE CONTROL SYSTEM PANEL - II	5-29
	DUPLINE CONTROL SYSTEM PANEL - III.....	5-30
	UNINTERRUPTIBLE POWER SUPPLY	5-31

SIDEWALK LIGHTS	5-32
CONDUIT AND JUNCTION BOX	5-33
MOTORIST AID TELEPHONE SYSTEM CALL BOXES.....	5-34
WEATHER MONITORING STATION	5-35
MEDIUM VOLTAGE EQUIPMENT	5-36
P1 PANEL (SHOWN WITH PANEL OPENED)	5-37
P2 PANEL (SHOWN WITH PANEL CLOSED)	5-38
P3 PANEL (SHOWN WITH PANEL CLOSED)	5-39
P4 PANEL (SHOWN WITH PANEL CLOSED)	5-40
P5 PANEL (SHOWN WITH PANEL CLOSED)	5-41
CATHODIC PROTECTION RECTIFIER PANEL R1-S (SHOWN WITH PANEL OPEN).....	5-42
OPTICAL WATER SENSOR	5-43
FLOAT SWITCH WATER SENSOR.....	5-44
SMOKE DETECTOR.....	5-45
PONTOON RECEPTACLE	5-46
INTERCOM SYSTEM - I	5-47
INTERCOM SYSTEM – II	5-48
CONDUIT AND JUNCTION BOXES (MOUNTED ON CEILING)	5-49
ELECTRICAL CONDUCTORS (MOUNTED ON CEILING).....	5-50

SECTION 6

WEEKLY FREQUENCY	FORM
HH WEEKLY/MONTHLY INSPECTION AND MAINTENANCE.....	6-2
HH ELECTRICAL WEEKLY MAINTENANCE	6-3

MONTHLY FREQUENCY

HH ELECTRICAL PONTOON INTERIOR MAINTENANCE	6-4
HH CATHODIC PROTECTION LOG (ON-SITE).....	6-5A
HH CATHODIC PROTECTION LOG	6-5B

6 MONTH FREQUENCY

HH CABLE TENSION ADJUSTMENT	6-6
-----------------------------------	-----

ANNUAL FREQUENCY

HH PONTOON INTERIOR INSPECTION AND MAINTENANCE.....	6-7
HH ELEVATED STRUCTURE WEST.....	6-8
HH ELEVATED STRUCTURE EAST.....	6-9
HH ROADWAY INSPECTION AND MAINTENANCE.....	6-10

HH EXTERIOR INSPECTION NORTH	6-11
HH EXTERIOR INSPECTION SOUTH	6-12
HH ELECTRICAL PONTOON INTERIOR MAINTENANCE	6-13
HH ELECTRICAL EXTERIOR MAINTENANCE	6-14
3 YEAR FREQUENCY	
HH ELECTRICAL PONTOON INTERIOR MAINTENANCE	6-15
HH ELECTRICAL EXTERIOR MAINTENANCE	6-16
5 YEAR FREQUENCY	
HH PONTOON INTERIOR MAINTENANCE.....	6-17
HH ELECTRICAL EXTERIOR MAINTENANCE	6-18
10 YEAR FREQUENCY	
HH PONTOON INTERIOR MAINTENANCE.....	6-19
HH POST STORM AND POST EARTHQUAKE.....	6-20
HH PONTOON CELL WATER.....	6-21
HH MAINTENANCE FREQUENCY SCHEDULE.....	6-22
SECTION 7	
7.1 EMERGENCY CONTACTS.....	7-1
SECTION 8	
8.1 GOVERNMENT AGENCY INVOLVEMENT	8-2
8.1.1 WSDOT Northwest Region Bridge Branch, Bellevue	8-2
8.1.2 WSDOT Bridge and Structures Office, Olympia.....	8-2
8.1.3 Traffic Systems Management Center, Seattle	8-2
8.1.4 Washington State Patrol	8-2
8.1.5 WSDOT Region Incident Response Team.....	8-2
8.1.6 Department of Ecology	8-2
8.1.7 Seattle and Mercer Island Police Departments.....	8-3
8.1.8 Seattle and Mercer Island Fire Departments	8-3
8.2 STORMS.....	8-3
8.2.1 Pre-Storm and During Storm Inspections	8-3
8.2.2 Post Storm/Earthquake Inspection	8-5
8.3 SEVERE WATER LEAK	8-6
8.3.1 Severe Water Leak Procedure	8-6

8.3.2	Location of Emergency Equipment.....	8-7
8.4	COLLISIONS BY VESSELS AND OTHER FLOATING OBJECTS	8-8
8.5	FIRE.....	8-8
8.6	HAZARDOUS/FLAMMABLE MATERIAL SPILL	8-8
8.7	EARTHQUAKE.....	8-9
8.8	PUBLIC AND MEDIA INFORMATION	8-9

APPENDIXES

APPENDIX A

MEMORANDUM: EAST CHANNEL, I90 HOMER/HADLEY AND LACEY V. MURROW
BRIDGES

APPENDIX B

I-90 HHB/LVM FLOATING BRIDGE EMERGENCY RESPONSE PROCEDURE

APPENDIX C

FLOATING BRIDGE RAPID RESPONSE DAMAGE CONTROL TEAM